

**Gen2 Avenir Glass Stacker**  
**Installation guide**



**Parts**

Glass stacker  
Stacker bracket (in-line)  
Stacker bracket (2-way)  
Stacker bracket (3-way)  
Stacker bracket (4-way)  
Stacker bracket (end of run)

**Tools Needed**

Drill  
3/16" Allen Driver  
3/8" Nut driver  
8" Driver extension

# Gen2 Avenir Glass Stacker

## Installation guide

### Step one:

Remove all top caps and top cap retainers. This product will not be needed, the glass stacker come with new top caps and retainers.

### Step two:

Remove the standard porkchops and replace with stacker brackets as needed per per print



### Step three:

Install stacker by sliding down over stacker bracket.



## Gen2 Avenir Glass Stacker Installation guide

### Step four:

Connect stackers together with standard porkchop connectors and install top caps

